


EconoSnap

Instruction Sheet

Parts



Instructions for Hanging

Step 1

Place poster on a flat surface. Snap the Gotcha Holder open and insert poster (top and bottom). To close, snap the Gotcha Holder shut. **Fig. 1**

Note: It is easier to open and close the Gotcha Holder by starting at one end and working your way down the holder.

Step 2

Insert the GotchaClips into the holes in the pegboard. For best results, place the GotchaClips in holes separated by a difference equal to half of the length of Gotcha Holder. (i.e. If holder is 12" place clips 6" apart). **Fig. 2**

Step 3

Push Gotcha onto clips, you will hear a "SNAP". **Fig. 3**

Important note:

Please save and reuse the Gotcha Holder and GotchaClips for future projects.

